

ParkStone Manufacturing, LLC

Hearth Pad / Wall Pad Installation and Care Instructions

Thank you for purchasing a ParkStone Hearth Pad or Wall Pad! ParkStone Hearth Pads and Wall Pads are made with care for a lifetime of beauty.

Care: You may sweep or dust your ParkStone Hearth Pad or Wall Pad with an indoor broom or dust cloth. If more heavily soiled, you may wash your ParkStone Hearth Pad or Wall Pad with a mild soap and water solution. If you wish your ParkStone Hearth Pad or Wall Pad to have a high luster, you may apply a light treatment of “Mop & Glo.”

Hearth Pads

Installation: ParkStone Hearth Pads should be installed on a flat, even, and level surface and should be fully supported.

Wall Pads

Installation: Depending on local regulations, code and your specific stove, a gap may be necessary between your ParkStone Wall Pad and the wall. It is your responsibility to ensure all regulations for your specific stove and structure are followed. We recommend professional installation for all ParkStone Wall Pads.

Your ParkStone Wall Pad should be attached to **at least** two different studs. Screw spacing should be approximately every 12-14 vertical inches. Pre-drill holes through the ParkStone Wall Pad using a masonry bit from the front of the wall pad to line up with wall studs. Anchor your ParkStone Wall Pad to studs with screws of appropriate length.

Attention

Due to inherent physical properties of concrete, small hairline cracks (micro-cracks) may appear in the surface overtime. This is normal and does not affect structural integrity or performance of the pad. If cracking is severe or deep, repair and/or replacement may be required.

Rules and regulations may vary by location. You are responsible to ensure suitability and installation according to applicable regulations.